



K20 Compact Headend DVBS2 - DVBC, 8 to 16 MUX

The perfect balance between simplicity and efficiency

Ready to work compact headend that generates QAM multiplex from the services available in TV SAT transponders (DVB-S/S2/S2X). Stand alone solution for transparent transmodulation of any transponder from any of the 4 satellite polarities, and just a electrical plug (PSU included).

It is possible to combinate two K20 headends to achiveve a greater number of output multiplex. Both devices will be connected in loop mode (cascade), and it can be possible to manage the configuration of the whole solution with one of the K20 units set in master mode.

The headend allows its configuration throught a Web interface via Ethernet or WiFi (accessory ref. 216802 required).

Ref.	570104
Logical ref.	K20-20
EAN13	8424450221907

Other features

Number of transponders

20TP

Physical data

Net weight

6,941.00 g



Packaging info		Gross weight	7,500.00 g		
Box	1 pcs.	Width	298.00 mm		
	i pes.	Height	202.00 mm		
		Depth	76.00 mm		
		Main product weight	6,941.00 g		

Highlights


- Easy-to-install solution (Plug & Play): less cables and shoter installation time
- Pre-settings autoconfiguration: the user selects which preloaded configuration wants and the module configurates itself
- User web interface: Access to the headend configuration through Ehternet connection or a selfcreated WiFi network. The interface is perfectly adapted to any device: PC, smartphone or tablet
- Cloning function to replicate configurations between different installations
- Flexible number of input transponders: combination of two K20 units to obtain more transponders (up to 32). In this case, one of the modules will be the master and the other the slave
- Good thermal management thanks to its built-in heat sink and fans

Main features

- SID filtering allows the removal of undesired services inside a multiplex (enhanced occupation use)
- Compact design: 273x203x57 mm
- Zamak chassis provides high screening effect
- Great robustness

Application example


Televes[®]


















Functionalities

Using preloaded configurations

 A + C + Normania 	ः १८११ स्टब्स्	tri					1.1.0
= K20							-
۰ ۵	0.00	67			C. tar		0
ta warw 17	a –				-	4.88.7.6	
# ###							
	100	100	 Calcol Tracket I 	trained .		Lange and Lange	1
12 there is an					-	Concession of the local division of the loca	~
S' marcona				1.000			
-	.	011		20111	-	A 199800	*
		sale	1.	10000	S & STAR BEECH	Thete	4
A fitale	11	1154	1.t	+	-	(Second	
	2	01014	14			10/0455	5
19. Au		(TEMP)	1.4	Series		Sector Sector	-
	12	rinte	14	1000	B-BORGE BEASTS	Contraction of the local division of the loc	×
	14	10.00	10	#1178	B-COMPANY	E222223	~

These headends incorporate default preloaded configurations in the system depending on the number of transponders in the module. Simply select the desired configuration for the installation and apply it.

Wizard mode for guided configuration

 Mounter March 14 A Community PREDMAN 		
= K20		2
6 🚨 🛛 🧿	B ¹ 11	0
ta waren 19	Contraction of the local distance of the loc	
¢; ⊶… ⊒∃ X ∞…		
ф. ж.		ĥ
	N TO SURE DO T PART	a

The interface includes a "Wizard" mode to configure a unit or the joint configuration of two loop mode units. It offers a guided step-bystep configuration to ensure successful configuration, with led indication of the unit, selection of the desired preload configuration, and a summary of the applied configuration.

Ethernet network configuration

The second second second					
P = 5 a ministrativ	GIRGER !				* × × × Ø 1
					86vm
= K20					HN
11 m					
Products II .	rmmar 84				
41 wit:					a 11 11 11 1
Con case			 niew.	753 100	
ALC: NAME OF TAXABLE			 11/1/1	/ and the	
MB steers		10°			
06 mar 17					
2					
a					

Each unit has two Ethernet RJ45 connectors, one for network connection and the other one for loop mode link between units. Thanks to the interface it is possible to configure input parameters of the network connection: IP address, subnet mask, and default port link, as well as the DHCP client mode.

Cloning of headends configurations



The web interface allows to export/import files for duplicating units configurations, to use them in another intallations. This function helps to reduce time in typical installations, due of having previously a configured file. The exportation of these files also allows to have a headend configuration backup.

Status system window



+ + C Athender										> 0
= K20										-
D ++	1910									
n 0			-	•					0.00	**
				-					-	
		184 ×	*** ****	-					-	D
If there have		10.7 -	12-112-	-		8 1.4 ·	10-01-	A grant free	-	D
2 mainten		11+4	THE PARTY				ing's	miniation.	-	=
a		10.00 -					-	Charries.		
A come		1162-	1000000000	1.00	12	10 mm	1.548-11	10000000		12
2 50	😰 :Sat	(16.4 >	118++128+			💼 u.a	10411	+ 4 - (19+	-	Ð
	(2) 410	0.54.5	119411180	-	12	10 i ce -	19.834	0.000 ct 1000		8
8.99	5 v.a.		177-p111-7-1				4.975.75	areast 7 a	-	=

Secure configuration with password

The second secon		4
= <mark>K</mark> 20		51.00 M
Sh was Kittlersteiner		
pa constant las	ter haven in the	
· · · · · · · · · · · · · · · · · · ·	in the state	
S has	alater desire	
D managera	s	
Constant and a second s		
±		
Se anne		
• •		
		54

Protect the headend from unauthorized profiles by assigning a password to access the configuration edition. In addition, for those cases where there is more than one unit, both master and slave devices must have the same password.