

# Televés®



**H30FLEX**

**Refs. 593301, 593302  
593303, 593304  
593360, 593361**

**EN Digital processing handheld DVB Meter / Analyzer**

**Instruction Manual**



## Index

Safety requirements	4
Symbols and safety labels	4
Overview	5
Introducing the H30FLEX.	5
Key Features	5
General Specifications	6
Technical Specifications	7
Description of equipment components	8
Connectors and controls	8
Keyboard	8
Power supply	9
About battery	9
Before starting	11
Product operation	11
1. Channel Info	11
2. Spectrum	12
3. MPEG	13
4. System Scan	14
5. Satellite Test	15
7. Constellation	16
8. Echoes	17
9. Camera	18
10. Setup	19
Driver Installation (only for old hardware version with USB connector)	19
Web Application	20
1. Measurements	21
2. Plans	21
3. SCR	23
4. Quality Profiles	23
5.- Clone	23
6. Update	24
Error Messages	25
Repair service	26

## Safety requirements

### ● Product inspection

- Inspect the equipment for shipping damage. Should any damage be discovered, immediately file a claim with the carrier.

### ● Read and Follow All Instructions

- All the safety and operating instructions should be read prior to and followed while operating this product.

### ● Do not obstruct the ventilation slots

### ● Cleaning

- Follow the cleaning instructions contained in the Maintenance section of this manual.

### ● Attachments

- Do not use attachments that are not approved by the product manufacturer.

### ● Water and Moisture

- This product is splash water resistant but is not submersible.
- Do not place objects filled with liquids on or near the meter, such as glasses.

### ● Power Sources

- This product should be operated only from the type of power source specified (12VDC - 2A).
- Ensure that the voltage applied to the power connector does not exceed 15V. Higher voltages could damage the equipment
- Maximum consumed current: 2A

### ● Grounding or Polarization

- Do not bypass or defeat electrical plug polarization or grounding. Doing so will violate the warranty and may pose a risk of fire or electrocution.

### ● Wire Protection

- Ensure all connected wiring is routed correctly to avoid damage including pinching, excessive bends, or compression.

### ● Electrical Supply, Grounding, and Surge Protection

- Ensure that all local or national electrical codes are followed.

### ● Power Lines

- Always use caution and avoid operating this or any connected equipment near uninsulated power lines or any other hazards.

### ● Servicing

- There are no user serviceable parts except the battery. Do not attempt to service this product or remove covers other than the battery cover. Refer all servicing to qualified service personnel. Follow the instructions in this manual when replacing the battery.

### ● Heat

- The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products that produce heat.
- Do not place naked flame sources on the meter, such as lighted candles.

### ● Maximum current consumed by the meter: 2A

### ● Battery

- Battery must be replaced by qualified personnel, following the steps mentioned in the corresponding section.
- If the battery is replaced, the new one must have the same features, because there is risk of explosion. Furthermore, the new battery must be approved by the manufacturer. Otherwise, the company is not responsible for damages caused to the meter.
- Battery features:  
Li-Ion  
2600mAh 7.26V 19 Wh

## Symbols and safety labels



Recycle or dispose of used electronic devices properly.



Remove the battery from the equipment following the instructions given in this manual and dispose it properly



Replace the batteries only with the same type.



## Overview

### Introducing the H30FLEX.

New from Televés, a go-to meter designed with the needs of a DVB installer in mind.

The **H30FLEX** is a light weight, rugged unit, packed with all the features needed to install and troubleshoot a television system using DVB-S/S2, DVB-T/T2, DVB-C (Annex A/C) and QAM (Annex B) digital modulation as well as analog signals.

Available for the first time in such a portable and affordable package, its real time digital processing engine gives the installers a great precision measurements needed in today's fulfilment environment.



## Key Features

- **User friendly**, handheld DVB meter.
- Complete portfolio of Analog/Digital measurements with easy-to-read **pass/fail indicators**.
- **Quick and easy to use interface** with features such as Channel measurements, System Scans, Constellation Diagram, Spectrum Analyzer, Echoes, Datalogger, and more.
- Rugged, light weight, fully automatic, fast, and accurate.
- **Easy updates**.
- **1 GHz spectrum range** with selectable span.
- **PASS/FAIL Indicators**: Icons indicate if a measurement is good, bad, or in the warning zone for quick and easy status checks. Reduce installer entry errors and improve decision making.
- LNB powering, and SCR and DiSEqC parameters setup
- MPEG image visualization

## General Specifications

<b>Display</b>	2.8" TFT 400 x 240 full colour
<b>Weight</b>	510g (12.12lb)
<b>Dimensions</b>	175 x 100 x 52 mm / 6.9 x 3.9 x 2 in (H x W x D)
<b>Power Source</b>	Input: 100-240V~ 50-60Hz Output: 12VDC, 2A
<b>Battery</b>	Lilon smart battery (7.2VDC, 2300mAh)
<b>Operating Time</b>	Up to 4 hours
<b>Operating Temperature</b>	23°F to 104°F (-5°C to 45°C)
<b>Storage Temperature</b>	-4°F to 158°F (-20°C to 70°C)
<b>Humidity</b>	5% to 95% non-condensing
<b>Ruggedness</b>	Survives 1 m (3 ft) drop to concrete on all sides
<b>Communication Interfaces</b>	USB connector (old HW) / ETH connector (new HW) to download Datalogs and software updates
<b>Storage</b>	400 MB (internal) for measurements
<b>Power up time</b>	< 10 seconds

## Technical Specifications

<b>Frequency</b>	
Range	50 - 880 MHz and 950 - 2200 MHz
Resolution	125 kHz
Tuning	Frequency or channel
<b>Input</b>	
Impedance	75Ω F-type connector
<b>Spectrum Analyzer</b>	
Span	5, 10, 20, 50, 100, 200, 500 and Full span
Scale	5 and 10 dB/div
Auto and manual reference level	✓
Digital Measurements DVB-T (ref.593301,593302,593304 and opc.593231)	
MPEG image	✓
Modulations	CFDM (QPSK, 16QAM, 64QAM)
Power	45-110dBuV (25-120dBuV opt.593235)
CBER	9.9E-2 - 1.0E-6
VBER	1.0E-3 - 1.0E-8
MER	Up to 35dB
C/N	Up to 40dB
Echoes	✓
Constellation	✓
Digital Measurements DVB-T2 (ref.593302,593304 and opc.593232)	
MPEG image	✓
Modulations	COFDM (QPSK, 16QAM, 64QAM and 256QAM)
Power	45-110dBuV (25-120dBuV opt.593235)
LDPCCBER	9.9E-2 - 1.0E-6 (Pre LDPCCBER)
BCHBER	1.0E-3 - 1.0E-8 (Pre BCHBER or Post LDPCCBER)
Link Margin	Up to 30dB
MER	Up to 35dB
C/N	Up to 40dB
Echoes	✓
Constellation	✓
Digital Measurements DVB-C (ref.593303,593304 and opc.593233)	
MPEG image	✓
Modulations	16QAM, 32QAM, 64QAM, 128QAM and 256QAM
Power	45-110dBuV (25-120dBuV opt.593235)
CBER	1.2E-2 - 1.0E-8
MER	Up to 38dB
C/N	Up to 40dB
Constellation	✓
Digital Measurements QAM-B [ITU J.83-B] (ref.593360)	
MPEG image	✓
Modulations	64QAM and 256QAM
Power	45-110dBuV (25-120dBuV opt.593235)
Pre-BER y Post-BER	1.0E-3 - 1.0E-8


MER	Up to 38dB
C/N	Up to 40dB
Constellation	✓
Digital Measurements (DVB-S)	
MPEG image	✓
Power	45-110dBuV (25-120dBuV opt.593235)
CBER	9.9E-2 - 1.0E-6
VBER	1.0E-4 - 1.0E-8
MER	Up to 20dB
C/N	Up to 20dB
Constellation	✓
Digital Measurements (DVB-S2)	
MPEG image	✓
Modulations	QPSK, 8PSK
Power	45-110dBuV (25-120dBuV opt.593235)
Link Margin	Up to 10dB
MER	Up to 20dB
LDPCCBER	9.9E-2 - 1.0E-6 (Pre LDPCCBER)
BCHBER	9.9E-2 - 1.0E-8 (Pre BCHBER or Post LDPCCBER)
Constellation	✓
Analog Measurements	
Level	25 - 125dBuV
V/A	✓
C/N	Up to 45dB
Features	
Terrestrial channel plans	CCIR, CCIR + LTE, OIRT, KBW, FCC, DAB, SIM
Satellite channel plans	68E INTEL C, 68E INTEL, 42E TURK, 39E HELLAS, 33E EUTEL, 28E EUTEL, 28E ASTRA, 26E BADR, 25E EUTEL, 23E ASTRA, 21E EUTEL, 19E ASTRA, 16E EUTEL, 13E HOTB, 10E EUTEL C, 10 EUTEL, 9E EUTEL, 7E EUTEL, 4E ASTRA, 1W THORS, 1W THOR6, 5W EUTEL, 5W EUTEL, 7W NILE, 30W HISPAA, 48W AMZC, 48W AMAZ, SIM.
User channel plans	✓
Units	dBuV, dBmV, dBm
Preamp powering	13, 18, 24Vdc (max. current 475, 370, 140mA)
LNB powering	13, 18Vdc (max. current 475, 370mA)
LNB tone	22KHz
SCR(EN50494) dCSS (EN 50607)	✓   Opt.593234
DiSEqC	✓

EN

Specifications are subject to change without notice.


## Description of equipment components

### Connectors and controls









1. External power connector (12VDC).
2. LCD display.
3. Keyboard and LED indicators
4. USB connector (old HW) / ETH connector (new HW)
5. RF F-connector (see options below).

#### F-connector options




### Keyboard



1.  **Device On/Off button:** To turn the equipment off, press and hold for approximately 3 seconds.
2.  **Back button:** Return to the previous menu or close a parameter entry window.
3.  **Home button:** Return to the main menu.
4. **Navigation buttons:** Used to scroll through options.
5.  **OK Button:** To confirm selection.
6.  **Setup button:** Parameter window for the current function.
7. **LED Powering:** Indicates if the equipment is powering an external load.
8. **LED Charging Battery:** LED flashes while the battery is charging.
9. **LED Power ON:** Illuminated when the equipment is on.

## Power supply

A DC adapter is provided to power and charge the meter. Plug the adapter into a properly grounded electrical supply and the power connector on the side of the unit.








When external power is supplied, the battery management system automatically controls the charging process.

A battery icon indicates the charge status of the battery.

When the battery is fully charged, the battery icon is completely filled. As the battery discharges, the amount the icon is filled decreases in steps.

The icon shows 5 states representing the approximate battery charge:

-  - Battery charge less than 5%.
-  - Battery charge between 5% and 25%.
-  - Battery charge between 25% and 50%.
-  - Battery charge between 50% and 75%.
-  - Battery charge greater than 75%.

From a fully discharged state, a full charge takes approximately 8 hours and a 3 hour charge will provide approximately a 75% charge.

The charge management system will detect various conditions preventing charging, such as a battery that is over a safe temperature.

## About battery

### Important:

If the meter detects a shortcircuit or over consumption, and it is not connected to the power supply, it automatically shuts down.

To turn it on again, it is necessary that it is connected to tyeh power supply.


### To maximize battery life:

- ▶ Avoid fully discharging the battery.
- ▶ The battery should always be charged with the battery pack attached to the device and using the supplied DC adapter or applying a constant voltage within the specified range (12-15VDC).
- ▶ For long term storage, keep the unit at room temperature, or about 25° C. Start with a charged battery and re-charge the battery every 2 to 3 months.


### Battery replacement:

It is recommended that the replacement of the battery is carried out by qualified personnel following the following instructions:


- ▶ Disconnect the meter from the power supply:




- ▶ Turn the H30FLEX off




- ▶ Place the new battery and then connect it to the power board




- ▶ Remove the screws from the backside




- ▶ Replace the back cover of the meter. Make sure that the cable is not trapped between the two covers




- ▶ Open the back cover



- ▶ Replace the screws of the back cover






- ▶ The battery is located at the bottom of the meter. Carefully remove the connector from the power board, and then remove the battery




## Before starting

The first time you turn your H30FLEX on, please follow the next steps for a proper configuration:

- 1.- Select the language using  and 



- 2.- Select the geographical area, so the proper channel plans will be enabled:



- 2.- Register your H30FLEX:

- 2.1.- Read the QR code using your mobile phone or tablet. Or enter the web url shown at the bottom of the screen in the address bar of your computer:



- 2.2.- Register your H30FLEX in our web. Once the process is completed, you will get a PIN code. Enter the PIN in your H30FLEX:



- 2.3.- If the PIN is OK, you have finished the registration process.

**NOTE:** Options 593234 (dCSS) and 593235 (Extended terrestrial input level range) will be activated automatically in your H30FLEX whenever you register it within 30 days after you turn it on for the first time.

EN

## Product operation



### 1. Channel Info

Analog and digital channels are very different in terms of signal content and power distribution and thus require the advanced SLM techniques provided in the Televes **H30FLEX**.

In analog mode, video and audio levels, V/A and Carrier to Noise (C/N) are measured.

In digital mode measurements depend on the modulation:

DVB-S: Power, C/N, MER, CBER, VBER

DVB-S2: Power, C/N, MER, LDPCBER, BCHBER

DVB-T (Ref. 593301, 593302, 593304 and Opt. 593231): Power, C/N, MER, CBER, VBER

DVB-T2 (Ref. 593302, 593304 and Opt. 593232): Power, C/N, Link Margin, LDPCBER, BCHBER


DVB-C (Ref. 593303, 593304 and Opt. 593233): Power, C/N, CBER, MER

QAM-B [ITU j.83-B] (Ref. 593360): Power, C/N, CBER, MER

ISDB-T/Tb (Ref. 593361): Power, C/N, CBER, VBER, MER

**1.1. Main window**

Below is a capture of a Channel Info window with a brief explanation of its features.



(powering), and DiSEqC. In addition, a SCR icon will be shown in the bar at the top (SCR3) to indicate that the slot is enabled.

While the slot is enabled, all the setting changes of the meter, will be applied to the currently slot (SCR3).

- **Tuning:** Channel, Frequency
- **A/D:** Auto, Analog, Digital.
- **Save datalog:** Saves the current scan measurements. You can see the datalogs using the remote control application.



**2. Spectrum**


Real-time processing speeds ensure capture of any fast, intermittent plant impairments.

Due to the accuracy and level of detail provided by this spectrum analyzer, the **H30FLEX** is the ideal tool for identifying and locating noise, interference, ingress and other waveforms that may be affecting cable services quality.

**1.2. Setup**



Press **SETUP** to change the Channel Info options.




**2.1. Main window**


Below is a capture of a Spectrum window with a brief explanation of its features:


- **Band:** Terrestrial/Satellite
  - **Powering:** Selects the LNB powering
  - **DiSEqC (only satellite band):** Selects DiSEqC parameter (Sat A, sat B, sat C, sat D)
  - **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots)
- When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slot frequency (1210MHz) and will set the slot with the meter parameters: frequency, band





2.2. Setup

Press  to change Spectrum options.



- **Band:** Terrestrial/Satellite
- **Powering:** Selects the LNB powering
- **DiSEqC (only satellite band):** Selects DiSEqC parameter (Sat A, sat B, sat C, sat D)
- **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots)  
When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slot frequency (1210MHz) and will set the slot with the meter parameters: frequency, band (powering), and DiSEqC. In addition, a SCR icon will be shown in the bar at the top (SCR3) to indicate that the slot is enabled.

While the slot is enabled, all the setting changes of the meter, will be applied to the currently slot (SCR3).

- **Aim antenna:** Emits a modular audible signal with frequency directly proportional to signal level in the spectrum trace relative to reference level. It is recommended to set the reference level manually, as well as to select the span to include a frequency range wide enough.  
The audible signal becomes continuous when the signal level is close to the reference level. Then it is necessary to increase the reference level to get a more accurate adjustment.  
This is a useful feature to point antennas without having to look at the display
- **Span:** 5MHz, 10MHz, 20MHz, 50MHz, 100MHz, 200MHz, 500MHz, Full.  
Set the span of the spectrum. To easily change the span, use the **OK** Button to decrease the span and the **Back** Button to increase the span.
- **Ref. Level:** Select the reference level of the spectrum graph
- **dB/div:** 5 dB/div, 10 dB/div
- **Tuning:** Channel, Frequency
- **A/D:** Auto, Analog, Digital.
- **Save datalog:** Saves the current scan measurements. You can see the datalogs using the remote control application.




3. MPEG


The **H30FLEX's** MPEG feature will show the image of the selected service.


3.1. Main window

Below is a capture of a MPEG Info window with a brief explanation of its features:



1.2. Setup

Press  to change the Channel Info options.



- **Band:** Terrestrial/Satellite
  - **Powering:** Selects the LNB powering
  - **DiSEqC (only satellite band):** Selects DiSEqC parameter (Sat A, sat B, sat C, sat D)
  - **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots)
- When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slof frequency (1210MHz) and will set the slot with the meter parameters: frequency, band (powering), and DiSEqC. In addition, a SCR icon will be shown in the bar at the top (SCR3) to indicate that the slot is enabled.

While the slot is enabled, all the setting

changes of the meter, will be applied to the currently slot (SCR3).

- Volume




4. System Scan

This function scans the selected channel plan and detects every existing analog and digital channel in real time to determine the overall frequency response of the system.


The scan measurement leverages the location based thresholds to clearly show whether or not signal levels comply with the cable system's specifications with their green, yellow and red bars. This gives an easy-to-understand real-time view of the system, including the BER and MER values of the selected channel.


4.1. Main window

Below is a capture of a System Scan window with a brief explanation of its features:



### 4.2. Setup

Press  to change the System Scan options.



- **Band:** Terr, Sat
- **Powering:** Selects the LNB powering
- **DiSEqC (only satellite band):** Selects DiSEqC parameter (Sat A, sat B, sat C, sat D)
- **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots)  
When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slot frequency (1210MHz) and will set the slot with the meter parameters: frequency, band (powering), and DiSEqC. In addition, a SCR icon will be shown in the bar at the top (SCR3) to indicate that the slot is enabled.

While the slot is enabled, all the setting changes of the meter, will be applied to the currently slot (SCR3).

- **Digital tuning:** If it is ON, allows to see MER and CBER measurements when a digital channel is selected and the user presses Ok button.
- **Span:** Select the number of channels showed in the bar graph
- **Ref. Level:** Select the reference level of the bar graph
- **Save datalog:** Saves the current scan measurements. You can see the datalogs using the remote control application

This function checks that the input signal corresponds to the selected satellite, and at the same time checks the proper reception of the selected transponders (from 1 to 4 transponders). To do that, the meter performs all the measurements on those transponders.

First of all the user must select the channel plan of the satellite towards which the antenna is oriented.

Then the user must select the transponders on which you want to carry out the measurements (see Setup section of this function).

The information necessary to verify the satellite is extracted from these channels, and the measurements of the selected transponders are displayed.


### 5.1. Main window

Below is a capture of a Satellite Test window with a brief explanation of its features:



## 5. Satellite Test

### 5.2. Setup

Press  to change the Ssatellite Test options.



- **Powering:** Select the powering of the LNB if needed.
- **DiSEqC:** Select the SAT of the DiSEqC command.
- **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots) When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slot frequency (1210MHz) and will set the slot with the meter parameters: frequency, band (powering), and DiSEqC. In addition, a SCR icon will be shown in the bar at the top (SCR3) to indicate that the slot is enabled. While the slot is enabled, all the setting changes of the meter, will be applied to the currently slot (SCR3).
- **Ref. Level:** Select the reference level of the bar graph.
- **Channels:** Select the number of channels as well as the channels from the channel plan.

white bar indicating the level of the audio carrier.

### 6.1. Main window

Below is a capture of a Learning Plan window with a brief explanation of its features:



## 6. Learning plan

Analyzes the input signal to the meter and automatically detects all channels.

This feature automatically identifies the channels as either analog or digital and performs measurements on each.

A bar graph is displayed with the height representing the power for digital channels and the level of the video carrier for the analog channels.

The measurements made for analog channels are video carrier level and V/A. For digital channels the measurements are power and C/N.

The analog channels will have an extra, smaller



## 7. Constellation

Digital video often does not show signal impairment until it is too late due to the small margin between acceptable quality and failure.


Constellation diagrams are an indispensable tool to help detect the presence of noise, phase jitter, interference, and gain compression, all of which impact overall signal quality and thus reduce Modulation Error Ratio (MER).

Ideally, each of the symbols in a constellation diagram should display a clean dot indicating a perfect signal.

The **H30FLEX's** real time constellation, allows the installer to assess the size and shape of the build up of dots indicative of problems which contribute to bit errors leading to service disruption


### 7.1. Main window

Below is a capture of a Constellation window with a brief explanation of its features:



### 7.2. Setup

Press  to change Constellation options.



- **Band:** Terr, Sat
- **Powering:** Select the powering of the LNB if

needed.

- **DiSEqC:** Select the SAT of the DiSEqC command.
- **SCR (only satellite band):** Selects the SCR parameters (multiswitch, standard and slots) When a slot is enabled (for example slot 3, freq. 1210MHz), the meter will tune into the slot frequency (1210MHz) and will set the slot with the meter parameters: frequency, band (powering), and DiSEqC. In addition, a SCR will be shown in the bar at the top (SCR3) to indicate that the slot is enabled.

While the slot is enabled, all the setting changes of the meter, will be applied to the currently slot (SCR3).

- **Zoom:** OFF, 1<sup>st</sup>, 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup>.

Select a quadrant of the constellation to be represented for more detailed view. Select Zoom OFF for the full constellation.

- **Tuning:** Channel, Frequency

- **Save datalog:** Saves the current scan measurements. You can see the datalogs using the remote control application.



## 8. Echoes


It is important to check that no echoes can cause problems in the reception of DVB-T, DVB-T2 or ISDB-T/Tb signals.

This feature you allows to visualize the echoes of the received signal, helping the installer to minimize them as much as possible for optimal signal reception.


In addition to the echoes graph, this function shows the channel power and MER measurements, as well as the FFT mode, the guard interval, and the Cell ID.


### 8.1. Main window

Below is a capture of a Ecos window with a brief explanation of its features:



**8.2. Setup**

Press  to change Echoes options.



- **Powering:** Off, 13V, 18V, 24V.
- **Tuning:** Channel, Frequency
- **Units:** us, Km



**9. Camera**

This feature allows the H30FLEX meters to have an analog video and audio input using an external USB 2.0 adapter, with capability to digitize the analog input signals.


It is specifically aimed for installation and maintenance of analog video surveillance systems.

The supported interface is composite RCA (S-VHS).

The input video formats that can be displayed are the following:


- NTSC: 720x480 @ 30fps
- PAL: 720x576 @ 25fps

To run the feature you just have to connect the input signal to the adaptor provided with the H30FLEX, making sure that the adaptor is connected to the USB input of the meter. If there is something wrong, the next screen will be shown:



**8.1. Main window**

Below is a capture of a Camera window:





## 10. Setup

Change main configuration settings:



- **Band:** Terr, Sat
- **Ter. Network:** Aerial, Cable
- **Terr Plan:** FCC STD, FCC RETURN, FCC IRC, FCC HRC, FCC OFFAIR, CCIR, and customers plans
- **Sat Plan:** F68E INTEL C, 68E INTEL, 42E TURK, 39E HELLAS, 33E EUTEL, 28E EUTEL, 28E ASTRA, 26E BADR, 25E EUTEL, 23E ASTRA, 21E EUTEL, 19E ASTRA, 16E EUTEL, 13E HOTB, 10E EUTEL C, 10 EUTEL, 9E EUTEL, 7E EUTEL, 4E ASTRA, 1W THOR5, 1W THOR6, 5W EUTELC, 5W EUTEL, 7W NILE, 30W HISPA, 48W AMZC, 48W AMAZ, SIM, and customers plans
- **Sat. Freq.:** IF, real Freq.
- **Sat. LNB:** Universal, C Band, Other.  
If Other is selected, you must enter the frequency.
- **Restore Powering:** On/Off. When you turn your H30FLEX on, the meter will set the last LNB configuration automatically whenever this parameter is On.
- **Language:** English, Español.
- **Units:** dB $\mu$ V, dBmV, dBm
- **Quality profiles:** Trunk, Tap, End Line, Ground.

Different thresholds are available for different testing locations.

- **Analog Standard:** Selects the standard for the analog channels and changes automatically the audio carrier to a value according to the selected standard.

- **Audio Carrier:** 4.5 MHz, 5.5 MHz, 6.0 MHz, 6.5 MHz.

- **Volume**

- **Time and Date:**

Set current time (hour and minutes) and date (day of the month, month and year).

- **Energy:**

Auto suspension

Auto shutdown

- **USB Storage (only old hw version):** Connect your H30FLEX to your computer using the USB connector and turn USB Storage ON, so you can use your H30FLEX as a storage unit.

- **Update firmware:** See section *Firmware update*

- **Reset configuration:** Resets the H30FLEX to factory settings


- **Licenses:** Shows a list with all the licenses included in your H30FLEX

- **About SW**


- **About HW**

## Driver Installation (only for old hardware version with USB connector)


1. Connect your H30FLEX to your computer using the USB
  - 2.- Depending on your Windows versión and configuration, it may happen that your computer installs automatically the corresponding driver.
  - 3.- If it does not occur, you must follow the next steps:
- 3.1.- Open the *Control panel*



3.2.- Select *Device Manager*




3.3.- Select *Other devices* and right-click on it




3.4.- Select *Update driver*

3.5.- Select the option that allows you to find the driver in your computer.

3.6.- Select *Network adapters* from the list



3.7.- Select *Microsoft Corporation* from the list of manufacturers and *Remote NDIS based Internet Sharing Device* from the list of network adapters:



3.8.- Wait until the driver is installed

Depending on the Windows version installed on your PC, you may have problems when installing the driver. If this happens, try the following method:


1.- Download the driver file from this link:

<http://h30flex.televes.net/driver/rndis.zip>


2.- Unzip the attached file in any directory on your PC (after unzipping it there will be 2 files, RNDIS.inf and rndis.cat)

2.- Connect your **H30FLEX** to your computer using the USB

3.- Open the *Control panel* and select the menu *Device Manager*. In the list of *Other devices*, check that the RNDIS icon has the warning advice (the triangle with the exclamation mark)




4.- Open the folder where you saved the driver previously. Right-click on the RNDIS.inf file and select *Install*:



5.- After this, the RNDIS device should disappear from *Other Devices* and appear under *Network Adapters*:





## Web Application

1.- If your **H30FLEX** is an **old hardware version** one, the first thing that you must do is to install the driver. Once you have installed the corresponding driver, open a web browser in your computer (Chrome recommended).

Type **http://h30.flex** in the address bar of your web browser and press Enter.

Then you can see the home window of the **H30FLEX** web application.

2.- If your **H30FLEX** is a **new hardware version** one, connect your H30FLEX to the network using the Ethernet connector. Then you must find out the IP of your H30FLEX in the *Setup -> About Hardware* menu.


Then, type your H30FLEX IP in the address bar of your web browser and press Enter.

Then you can see the home window of the **H30FLEX** web application:




## 1. Measurements

In this window, you can see all the datalogs saved in your H30FLEX. They are grouped by date in a calendar:





To change the display mode from calendar mode to list mode, just click on the corresponding button placed at the top of the left button panel:




Using the buttons placed at the top right of the screen, you can remove the selected Datalogs or download them to your computer in .xls format (it will be generated a .xls file for each Datalog and they all will be downloaded together in a .zip file)

Clicking on a the corresponding button of a Datalog of the list, the measurements of that Datalog will be displayed:



The customer channel plans can be edited:



## 2. Plans

In this window, you can see all the channel plans of your H30FLEX.

They are grouped in three categories: Terrestrial, Satellite and Customer.

The Terrestrial and Satellite channel plan are the standard channel plans of the corresponding band.


These plans can be removed from the meter, but they can not be edited. However, you can make a copy of one of them to build a new customer channel plan from it.

The duplicated plans will appear in the Customer list automatically.

You can create a new channel plan from an existing one by clicking on the corresponding button. Or you can start from scratch, by clicking on the “New custom plan” button:



The application also allows to configure the channel plans according to the geographic area you will use the meter. When you turn the meter on for the first time, you must select the language and the, you must select the geographic area. So, the channel plans corresponding to that area will be available in your H30FLEX. Using the function "Configure plans by zone", you can change the geographic area whenever you want:




Click on the geographical region you work in

When you change the area, all the plans of your H30FLEX will be removed and the new channel plans corresponding to the selected area, will be upload to your meter.

In addition to the channel plans corresponding to the selected area, it is possible to add other standard channel plans corresponding to other geographic areas (this is specially helpful for those places located near the frontier between two areas). To do that, click on the "Channel plan repository" button:

Unfold to see the list with the channel plans corresponding to the area  
 Once you have selected the channel plans, click this button to upload them to the meter




Check the plans you want to upload to your meter

The channel plans added from the repository will be uploads to your H30FLEX, but none of the channel plans in your meter will be removed.

### 3. SCR


In this window, you can setup the multiswitches.

The H30FLEX includes a list of multiswitches by default, but you can add more or edit any of the existing ones.



### 4. Quality Profiles


Using the web application you can add new quality profiles. The H30FLEX has two pre-defined quality profiles (head-end and outlet) that can not be edited, but they can be duplicated.



The duplicated quality profiles are saved in the custom quality profiles, and the custom quality

EN


profiles can be edited:



### 5.- Clone


Using this feature it is very easy to have the same configuration in all your H30FLEX meters. You only have to export the configuration of the H30FLEX that you want to copy, using the Export feature. So, the configuration will be saved in a file on your computer. Then, connect other H30FLEX where you want to copy the configuration to and select the Import feature.

Click to display the function



### 6. Update

In this section you can update the firmware of your H30FLEX. The process will be different depending on the hardware version of your H30FLEX.



1.- If your H30FLEX has **old hardware version** (that is, it has an USB connector):

The first thing that you must do is download the update file from the web of Teledesic and save it in your computer.

Then, select "Manually updating firmware" and use the browser to select the the update file.

2.- If your H30FLEX has **new hardware version** (that is, it has an Ethernet connector):

If you H30FLEX in connected to the internet, the system will detect automatically if your meter is already updated by clicking on "Last firmware version". If it is not, then you can download the new version and install it automatically from this menu.

If you get the update file from your distributor, you can install it in your H30FLEX by clicking on "Manually updating firmware".

## Firmware update

There are two ways to update the firmware of your meter.

The first one is using the web application, explained in the paragraph 4. *Update* of the section *Web Application*

**But, if your H30FLEX has an old hardware version, there is another way to update it:**

The second one is using the USB Storage feature of the Setup Menu (see section 9. *Setup* of the point *Product Operation*).

To update the firmware using this procedure, follow the next indications:

- 1.- The first thing that you must do is download the update file from the web of Televes and save it in your computer.
- 2.- Turn your H30FLEX on
- 3.- Press the Home button to go to the Main menu
- 4.- Select Setup
- 5.- Select USB Storage
- 6.- Turn USB Storage ON
- 7.- Connect your H30FLEX to your computer using the USB connector
- 8.- Then find the unit called **H30FLEX** in your computer and open the folder. You'll see a folder called *updates*
- 9.- Copy the two files corresponding to the update (*updater* and *version*) to the *updates* folder in the H30FLEX unit.
- 10.- Unmount the H30FLEX unit in your computer
- 11.- Select the *USB Storage* feature in the *Setup* menu of your **H30FLEX** to turn it off
- 12.- Select the *Firmware update* feature in the menu of your **H30FLEX** and press the OK button to confirm.
- 13.- Then a message will appear indicating that the **H30FLEX** is being updated. Wait until the **H30FLEX** resets automatically

## Error Messages

### LOW BATTERY

Indicates that the battery is about to finish. The battery icon is red now. It is recommended to connect the meter to the external power source.

### LOW BATTERY Shutting down

Some time after the LOW BATTERY message appears (time varies depending on the functions used), it will appear this message. If the meter is not connected to the external power source, it will switch off.

### BAD POWER Unplug power source

This message appears when the meter is connected to an external power source that does not supply it the right power. Please, use only the power source provided with the **H30FLEX**.

### SHORT-CIRCUIT Check installation

This message appears when the meter detects a short-circuit at the RF input. It is recommended to check the installation to find out why the short-circuit is produced.

### DC OUTPUT LIMIT EXCEED Switch DC OUTPUT off

This message appears when the meter detects an excessive consumption from the device that is being powered. It is recommended to turn off the powering feature of the **H30FLEX**.

### DC AT RF INPUT Check installation

This message appears when the meter detects DC at the RF input that is not generated by the **H30FLEX**. It is recommended to check the installation.

## Maintenance

Always disconnect the unit before cleaning. Use only a mild solution of detergent and water applied with a soft damp cloth. Dry thoroughly before use.

Do not use aromatic hydrocarbons or chlorinated solvents. These products may damage the unit.

Do not use alcohol or alcohol based products on the front panel, especially the display. These products may damage the unit.

## Technical support

For any questions, contact Technical Support at [www.televes.com](http://www.televes.com)

Before contacting Technical Support for repair, read the manual to ensure proper use and attempt to RESET the unit to clear any problems.

## Repair service

Do not return the unit without first contacting Televes Technical Support.

If the unit needs to be returned, Televes will arrange for free shipping. The unit will need to be appropriately packed for shipping.

In compliance with IATA Regulations, when using our shipping service follow these instructions:

- ▶ Label the package.
- ▶ The equipment should fit as snugly as possible in the box. It is recommended to use the original packing materials.
- ▶ Attach the precaution label to the package.



Failure to comply with these shipping requirements may result in the shipping agent rejecting the package.

## Warranty

- A) Televes warrants, only to the original Purchaser, all Products be free from any defect in materials or workmanship for a period of one (1) year, six (6) months for the battery, from the date of original purchase, unless otherwise specified.
- (B) Televes shall, free of charge and in its sole discretion, either repair, replace with a new or factory reconditioned equivalent, or refund the purchase price of the Product(s), that has been determined by Televes to be defective in material or workmanship, subject to the limits of this warranty.
- (C) This warranty excludes any inoperability resulting from:
- (I) use or installation that is not in strict compliance with the written instructions and specifications;
  - (II) any modification or alteration performed by any third party not authorized in writing by Televes;
  - (III) service or repair performed by any third party not authorized in writing by Televes;
  - (IV) misuse, abuse, intentional harm, or lack of reasonable care;
  - (V) fire, ice, snow, rain, wind, water, volcano, excessive heat or cold, lightning, flood, power surge, earthquake, or any other acts of God;
  - (VI) war, crime, strike, riot, electro-magnetic pulse, or any other acts beyond the control of Televes;
  - (VII) shipping.
- (D) All claims under the terms of this warranty must be made in writing, by the original Purchaser, within fourteen (14) days of the defect being known to the Purchaser. Such claims shall be accompanied by a description of any material facts related to the claimed defect and the invoice or other proof of original purchase date and price. If Televes so requests, the Purchaser shall, at Purchaser's expense, deliver the claimed Product(s) to Televes, within 14 days of the date of the return authorization. Under no circumstances shall the Product(s) be returned to Televes without a return authorization.
- E) Any refund to the Purchaser, shall be limited to the purchase price of the Product(s), excluding any applicable taxes, duties, freight costs, removal costs, installation costs, or any other charges incident to the purchase of the product.
- (F) Any damage caused by shipper shall be claimed with the shipper in accordance with the shipper's policies and procedures.
- (G) Televes shall in no event and under no circumstances be liable or responsible for any consequential, indirect, incidental, punitive, direct or special damages based upon breach of warranty, breach of contract, negligence, strict tort liability or otherwise or any other legal theory, arising directly or indirectly from the sale, use, installation or failure of any product acquired by Purchaser from Televes.
- (H) This limited warranty extends to the original Purchaser and cannot be assigned or transferred to any other party without the prior express written permission of Televes, which permission Televes may withhold for any reason or for no reason at all.
- (I) Televes will not assume any liabilities for any other warranties, whether statutory, express or implied, made by any other person.
- (J) Televes reserves the right to modify or discontinue this warranty at Televes's sole discretion without notification. No other warranties are expressed or implied.

-----  
DECLARACIÓN DE CONFORMIDAD ■ DECLARATION OF CONFORMITY ■  
DECLARAÇÃO DE CONFORMIDADE ■ DECLARATION DE CONFORMITE  
■ DICHIARAZIONE DI CONFORMITÀ ■ DEKLARACJA ZGODNOŚCI ■  
KONFORMITÄTSEKTLÄRUNG ■ ΠΙΣΤΟΠΟΙΗΤΙΚΟ ΣΥΜΜΟΡΦΩΣΗΣ ■  
FÖRSÄKRAN OM ÖVERENSSTÄMMELSE ■ ДЕКЛАРАЦИЯ СООТВЕТСТВИЯ ■  
ةقب اطم لآ نايب ► [www.doc.televes.com](http://www.doc.televes.com)  
-----



European technology **Made in**  **EU**rope

